



promate.net Lifestyle Technology

Match

**Ergonomically Designed Lightweight Neckband
Bluetooth® Headset**



User Guide

Introduction

Stunningly distinctive. Design meets functionality. Superior audio experience. That's Match for you. This stereo headset with Bluetooth® wireless technology is a real head-turner with its sporty, form fitting, lightweight neckband design. Functional button controls makes it easy to control your music or answer calls on the go while the magnetic lock keeps the headset in place when not in use. And with enhanced noise suppression technology and superior sound quality, this one of a kind headset is a must for all adventurers, travellers and sport buffs alike.

Packaging Contents

- Match
- User Guide
- USB Charging cable

Specification:

- Bluetooth® Version: Bluetooth V2.1+EDR
- Supported Profiles: A2DP1.2, HFP1.5, AVRCP, HSP
- Input Power: 5V, 300mA
- Output Power: 2 X10 mw
- Impedance: 16 Ohms
- Speaker Frequency: 20HZ-20KHZ
- Mic Sensitivity: -38dB
- Signal-to-noise Ratio: >80db
- Charging Time: 1-2 hours
- Playing Time: 5 hours
- Battery Capacity: 3.7V/150mAh
- Operating Distance: 10m

Features:

- Bluetooth® wireless technology stereo headset
- Sporty, form fitting, lightweight neckband design
- Button controls for easy control of music and calls.
- Magnetic lock keeps headset in place
- Listen to music and answer calls all at once
- Enhanced echo and noise suppression technology with built in CSR chipset
- Superior sound quality
- Standby time: 200 Hours

Compatibility:


Match may be paired as a headset to any compatible Bluetooth® enabled devices.

Precautions:

Please read all safety instructions and warnings thoroughly before using this product. Improper use of this product may result in damage to this or attached products. To keep the perfect performances of the product, never use it in the following conditions:

1. Moist or underwater conditions.
2. Conditions near the heater or high-temperature service.
3. Conditions with direct sunshine.
5. Never dismantle the product without due permission, otherwise it may nullify the warranty clauses.

Appearance & Interface Description:



1. Multifunction button
2. Previous Button
3. Next Button
4. Volume "+"
5. Volume "-"
6. Mic
7. LED Indicator
8. USB Charging Port
9. Magnetic Lock

Operation Instructions:

1. Basic Operation

- **Multifunction button:** Long press it to turn Match on/off , enter into pairing mode and answer/Reject calls.
- **Adjust the volume:** Press the "+" or "-" button to increase or decrease volume.
- **Next Button/Previous Button:**
To go backward or forward to the songs you like. Music player supported.
- **LED status indicator:** Below are LED status and it's corresponding mode:

LED status indicator	
Mode	LED status
Power on	Blue and Red LED blinks two times
Power off	Red LED blinks Two times
Pairing	Red and Blue LED blinks alternately
Incoming call	Red LED blinks continuously
Charging	Red LED stays on while charging

2. Pairing

- Press and hold the Multifunction button for at least 5 seconds until blue and red LED flashes alternately. Match is now on pairing mode.
- Activate Bluetooth® on your device and set it to search for new devices.
- Select "Match" from the list of found devices on your Bluetooth® devices and connect. If necessary, enter passcode 0000 to pair and connect Match to your device. Now you can use Match for calls or listening to music.

3. Music (Needs music player support)

- Press the "Previous Button" for about 2 seconds to skip to the previous track.
- Press the "Next Button" for about 2 seconds to skip to the next track.
- Press the Multifunction button once to play/pause music.
(Some phones may require you to start a media player first)

4. Call

- Press the Multifunction button to answer an incoming call.
- Press Multifunction button to end a call.
- To ignore an incoming call, double press the Multi-Function button.
- To redial the last call number, double press the Multi-functional button.
- When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.

6. Charging

Plug the USB cable included to a USB port and the other end into Match's charge jack. It takes 1.5 hours to fully charge Match. When charging, Red LED will light up .

Note: The lifetime of the battery will be significantly reduced if your Match is left uncharged for a long period. We recommend that you recharge your Match at least once a month.



www.promate.net